

Totally configurable

Total isolation

Low power

High precision: 0,1%



The GNL 48 is a programmable generator. The GNL 48 furnishing an output current or voltage, which limits and the slew rate are configurable.

FUNCTIONNALITY :

The GNL 48 furnishing

- voltage: 0-10 V,...
- or current: 0-20 mA, 4-20 mA,...

With two external buttons the user can choice the output value.

The GNL 48 is easily adaptable to all the industrial environments :

- Power supply : 110 and 230 Vac,
- Configurable output voltage or current,
- Low power : 3.2 VA,
- Wall and rail DIN mounting (Sym.).

SECURITY :

The GNL 48 has been conceveid in accordance with the problems met in the industrial environment :

- Galvanic isolation Output/Supply,
- Parameters saveguard on EEPROM,
- Noise immunity,
- WATCH DOG which supervises the program process,
- Stability towards ambient temperature variation,
- Precision 0.1 %.

DIALOGUE - CONFIGURATION :

The GNL 48 is configurable with a numerical connection from serial RS 232-C.

As a result of its programming simplicity, the user is able to make a complete reconfiguration in a record time: less than one minute.

The GNL 48 generator is able to dialogue without any interface but simply with any terminal emulation system (Cable and disk supply on demand).

Transmission format :

- 9600 BAUDS
- 1 start bit, 8 data bits, 1 stop bit.

With the terminal, the user will be able to :

- Visualize the resident configuration,
- Make a new configuration of the GNL 48.

The configuration modes allows the choice of :


- The slew rate,
- Output signal type and limits,
- the initial value.



TECHNICAL SPECIFICATION :

OUTPUT SPECIFICATIONS			SUPPLY	
TYPE	SCALE	PRECISION	110/230 Vac 50-60 Hz \pm 10%, 3.2 VA Max.	
CURRENT	0 / 20 mA	+/- 10 μ A	24 Vcc 3.2 VA Max (on demand)	
CURRENT	4 / 20 mA	+/- 10 μ A		
	Max. LOAD : 750 Ohms			
VOLTAGE	0 / 10 V	+/- 5 mV		
			ENVIRONMENT	
			Operating temperature range : 0 to 60°C	
			Storage temperature range : -20 to +85 °C	
			Ambient t° influence : < 0.005% / °C	
			Hygrometry degree : 85 % (not condensed)	
			Dielectric rigidity : 1500 Vac (Supply/Output)	
Immunity to electromagnetic perturbation in compliance with the CEI 801-4 / Level 3 standard				

CONNECTIONS AND LITTER :



To guarantee their technical specifications we recommend a spacing of at least 5 mm between each apparatus

LOREME 12, rue des Potiers d'Etain - Actipole BORNAY - B.P.5014 - 57071 METZ CEDEX 3
Téléphone 87.76.32.51 - Télécopie : 87.76.32.52

ACCESS TO TERMINAL MODE BY PSION:

Before all manipulation, put the plug "COMMS LINK" on the PSION.

To start-up the PSION, Dwell on the touch **ON** At this moment, the PSION displays a menu.

ACTION	DISPLAY	REMARKS
ON	RECH SAUV AGENDA CALC PROG EFFACE	Starting of the PSION
C	RECH SAUV AGENDA CALC PROG EFFACE	
C	DATE INFO ALARME COPIE RAZ COMMS	
C	DATE INFO ALARME COPIE RAZ COMMS	
EXE	TRANSMIT RECEIVE SETUP TERM AUTO	Enter in the COMMS subroutine
T	TRANSMIT RECEIVE SETUP TERM AUTO	
EXE	-	Enter in terminal mode.

Now you must link the PSION to the GENERATOR, by plugging in the RS 232.

ACCESS TO TERMINAL MODE BY PC:

To use GENERATOR with a PC, we must configure the PC in TERMINAL mode. For that, a terminal emulation programme called "KERMIT" (IBM-PC KERMIT-MS V2.26) is available. When the PC starts, (if you have this programme) type "KERMIT".

ACTION	DISPLAY
K E R M I T AND ENTER	IBM-PC kermit-MS V2.26 type ? for help kermit-MS>
S E T B A U D 9 6 0 0 AND ENTER	kermit-MS>
C O N N E C T AND ENTER	[Connecting to host, type Control-C to return PC]

Now you got to TERMINAL mode, so, link the PC to the GENERATOR, by plugging in the RS 232.



EXPLICATION OF CONFIGURATION:

REMARK: You must use CAPITAL letters for communication into terminal and generator.

For access to the menu press the touch "C".

ACTION	TOUCH	DISPLAY	REMARK
Asked to configuration	C	CONFIGURATION	
Choice in the menu	F E	LANGUAGE --->F --->E	Language: F rench E nglish
		CFG. LEC RECONF ---> C ---> R	
Choice in the menu	C R	RECONFIGURATION	Read C onfiguration R econfiguration

Chapter 1

Chapter 2

1) READING RESIDENT CONFIGURATION:

The reading has been asked by action on touch "C"

ACTION	TOUCH	DISPLAY	REMARK
Output resident configuration.		OUTPUT CURRENT LOW LIMIT 4 mA HIGH LIMIT 20 mA INITIAL VALUE 4 mA	type of output Limit low and high Initialization value
		SLEW RATE 75 s	Slew rate
End of reading		RET. MENU END ---> R ---> E	Menu presentation
	R E		R eturn to head menu E nd of configuration.



2) RECONFIGURATION:

The reading has been asked by action on touch "R"

ACTION	TOUCH	DISPLAY	REMARK
Reconfiguration		OUTPUT O - N ?	Asked to output reconfiguration
	N		N o, menu continue
		SLEW RATE O - N ?	Asked to slew rate reconfiguration
	N		N o, menu continue
		RET. MENU END ---> R ---> E	Proposition of return to the beginig of menu or end
	R	CONF RECONF --> C --> R	R eturn to head menu
	E	** OK **	E nd of configuration

Chapter 2.1

Chapter 2.2

2.1) OUTPUT RECONFIGURATION:

At the question " **OUTPUT**
Y - N ? " we have answered " Y "

ACTION	TOUCH	DISPLAY	REMARK
Reconfiguration		CURRENT O - N ?	Proposition of output current
	N		N o, menu continue
		VOLTAGE O - N ?	Proposition of output voltage reconfiguration
	N		N o, return to the beginig of menu

Chapter 2.1.1

Chapter 2.1.2

2.1.1) CURRENT OUTPUT CONFIGURATION:

At the question " **CURRENT**
Y - N ? " we have answered " Y "

ACTION	TOUCH	DISPLAY	REMARK
		LOW LIMIT ---> EXE	
Vaue of low limit	DIGITS AND ENTER	Type value	type the value (in mA) and enter
		HIGH LIMIT ---> EXE	
Value of high limit	DIGITS AND ENTER	Type value	Type the value (in mA) and enter
		INITIAL VALUE ---> EXE	
Initial value	DIGITS AND ENTER	a	Type the value (in mA) and enter

We now go to the proposition of slew rate

: Chapter 2



2.1.2) VOLTAGE OUTPUT RECONFIGURATION:

At the question " **VOLTAGE** " we answered " Y "
 Y - N ?

ACTION	TOUCH	DISPLAY	REMARK
		LOW LIMIT ---> EXE	
Low limit value	DIGITS AND ENTER	Type value	Type the value (in V) and enter
		HIGH LIMIT ---> EXE	
High limit value	DIGITS AND ENTER	Type value	Type the value (in V) and enter
		INITIAL VALUE ---> EXE	
Initial value	DIGITS AND ENTER	Type value	Type the value (in V) and enter

We now go to the proposition of slew rate reconfiguration

: Chapter 2

2.2) SLEWRATE RECONFIGURATION:

At the question " **SLEWRATE** " we answered " Y "
 Y - N ?

ACTION	TOUCH	DISPLAY	REMARK
		SLEW RATE ---> EXE	
Value of slew rate	DIGITS AND ENTER	Type value	Type the value (in s) and enter

Reconfiguration is ending we can go to the beginning of menu or stop configuration

: Chapter 2

Remark: In configuration mode, it is possible, if you see an error to return at the answered by action on "R".